



## Theta 40

### Theta 40- Multifunction Transducer

Product Code	TT40-	X	X	XXXXXXXXXXXX
<b>Product Type</b>	M42	1		
	M24	2		
	M20	3		
	M40 RS 485	4		
	M30	5		
	M01 RS 485	6		
	M00 LONBUS	7		
<b>Power Supply</b>	24-60V AC/DC		F	
	85-230V AC/DC		J	
<b>Version</b>	Standard			0000000000

### Commonly Used Ranges for Theta 40-

TT40-1F0000000000	Multi transducer: M42 Aux: 24-60VACDC; 4 Analog; 2 Digital; RS232 Interface
TT40-1J0000000000	Multi transducer: M42 Aux: 85-230VACDC; 4 Analog; 2 Digital; RS232 Interface
TT40-2F0000000000	Multi transducer: M24 Aux: 24-60VACDC; 2 Analog; 4 Digital; RS232 Interface
TT40-2J0000000000	Multi transducer: M24 Aux: 85-230VACDC; 2 Analog; 4 Digital; RS232 Interface
TT40-3J0000000000	Multi transducer: M20 Aux: 85-230VACDC; 2 Analog Outputs; RS 232 Interface
TT40-5J0000000000	Multi transducer: M30 Aux: 85-230VACDC; 3 Analog Outputs; RS 232 Interface



TT40-4J000000000000	Multi transducer: M40 RS485 Aux: 85-230VACDC; 4 Analog Outputs; RS 485 Interface
TT40-4F000000000000	Multi transducer: M40 RS485 Aux: 24-60VACDC; 4 Analog Outputs; RS 485 Interface

